

Speeduino 0.4.4.c							
Speeduino	Description	K11 ecu		Speeduino	Description	K11 ecu	
1	Inj1	3		21	O2 Sens	12	
2	Inj2	32		22	Tps input	73	
3	Inj3	31		23	Gnd	To others gnd	
4		/		24	Cam VR2+	44	
5	Inj4	4		25	Crank VR1+	16	
6		/		26		/	
7	Ign1	51		27	VR1-	43	
8	Ign2	52		28	5v	Relay 1 and 2	
9	gnd	6,71,48,23,		29		/	
10	gnd	14,11,28,34,55		30		/	
11		/		31		/	
12	gnd	To others gnd		32		/	
13	5v	46		33	Ign3	25	
14	Flex	48	Ac Relay	34	Ign4	24	
15	Fan	22	See Relay Scheme 1	35		/	
16	Fuel	1		36	Idle 2	2	
17	Tacho	18	12v->1k res->18	37	Pwn Idle	29	
18	Clutch	8	Malfunction light	38	VVT	76	Blower/Ac Load
19	Coolant	78		39		/	
20	lat	77		40		/	
				12v		37/54/58	
				Gnd		Chassis	
						27	See Relay Scheme 2

CUT GROUND CONNECTOR M184

28	+	Relay 1 (5v)	Nc	
Speed gnd	Gnd		Comm	15 (Speed.)
Relay +	Sign		No	22 (k11)